

DEPARTURE

Before Start Checklist

Voice Recorder		On
Cockpit Preperation		Complete
Light Test		Checked
Oxy & Interphone		Checked
Nav.& Displays		Auto/Norm
Fuel	Kgs	Pumps On
Galley Power		On
Emergency Exit Lig	nts	Armed
No Smoke/Seatbelt	s	On
Window Heat		As Req.
Hydraulics		Normal
Air Condition	2 Packs,	Bleeds On
Pressurisation	Isolation	Sw. Open
Autopilots		Disengaged
F/Director		On
Instruments	Cr	oss Checked
Autobrake		RTO
Speedbrake	Do	own Détente
Parking Brake		Set On
Stab.Trim Switches		Normal
W/Well Fire Warning	g	Checked
Rudder/Aleron Trim		Free & Zero
Gear Pins		Sighted
Clock		Set On
Take Off Briefing		Complete

Clear For Start/Pushback Checklist		
Papers	Aboard	
FMC/CDU	Set	
N & IAS Bugs	Set	
FuelKgs	Pumps On	
'A' Pumps (If Pushback)	Off	
Doors	Closed	
Flightdeck Windows	Locked	
A/Condition Packs	Off	
A/Collision Light	On	

After Start Checklist		
Electrical	Generators ON	
Window Heat	On	
Probe Heat	On	
Anti Ice	As Required	
Hydraulic Pumps	On	
AirCon	Packs On Trim Air On	
Pressurisation	Isolation Switch AUTO	
Yaw Damper	ON	
APU Bleed Switch	POFF	
APU	As Required	
Start Levers	IDLE Détente	
Ground Equipment	Removed	
Shoulder Harnesse	s Fastened	

Boeing	B737-600	
--------	----------	--

Reg: EC-ING

Callsign - EUROPA

Taxi Checklist		
Recall	Checked	
Flight Controls	Checked	
Flaps	Green Light	
MCP	Set	
Trims	Zero, Zero Units	
T/Off Briefing	Reviewed	
Cabin Report	Received	
Cockpit Door	Locked	

Before T/Off Checklist		
Recall	Checked	
Start Switches	On	
Taxi Lights	Off	
Lights	On	
Autothrottle	Armed	
Position Light	Strobe & Steady	
Transponder	On	

After T	/Off Checklist	
Lights	Off	
AirCon & Press.	Checked & Set	
Start Switches	As Required	
Landing Gear	Up & Off	
Flaps	Up, No Light	
Autobrake	Off	
No Smoking	Off/On	
Altimeters	Set & Cross Checked	
<u>At 10,000 Ft</u>		
Lights	Off	
Fasten Seatbelts	Off	
Cabin Altimeter	Checked	

Descent/App Checklist		
Anti Ice	As Required	
Air Cond & Press.	Set	
Start Switches	As Required	
Recall	Checked	
N & IAS Bugs	Checked & Set	
Autobrake	Set	
Approach Briefing	Completed	
<u>At 10,000 Ft</u>		
Lights	On	
Fasten Seatbelts	On	
Transition Level		
Altimeter & Inst.	Set & Cross Check	

ian@737ng.co.uk

www.737ng.co.uk Jan 2008



ARRIVAL

Before Landing Checklist

Start Switches	On
Recall	Checked
Speedbrake	Armed, Green Light
Landing Gear	Down, 3 Greens
Flaps	Green Light
Missed Approach Alt	itude Set
No Smoking	On

After Landing	Checklist
Transponder	Standby/Off
Radar Switches	Off
Speedbrake	Down Détente
Flaps	Up, No Light
Stabilizer Trim	Set
Autobrake	Off
Landing Lights	As Required
Position Lights	Steady
APU	Started
Start Switches	Off
Window Heat	As Required
Probe Heat Switches	Off
APU Generator Switches	On
F/Director Switches	Off
Shoulder Harness	Fastened

Parking Checklist		
Parking Brake	Set	
Electrical	On	
Start Levers	Cut Off	
Fasten Seatbelts	Off	
Anti Collision Light	Off	
Window Heat	Off	
Anti Ice	Off	
Electric Hydraulic	Pumps Off	
Fuel Pumps	Off	
Left Tan	<u>k Pump On If APU On</u>	
Air Condition	2 Packs & Bleeds On	
Pressurisation	Isolation Switch Open	
Exterior Lights	As Required	
IRS Selectors	Align, Off	
ADF & HF Radio	Off	

For Terminating Flights Only	
IRS Mode Selectors	Off
Galley Power	Off
Emergency Exit Lights	Off
Air Con Packs	Off
Displays	Dim
APU/Ground Power	Off
Battery Switch	Off

Boeing B737-600 Re

Reg: EC-ING

Callsign - EUROPA

BRIEFINGS

Before Start

CRM Standard RH or LH Seat Takeoff Pushback & Taxi Proceedures Runway Cond.& Use of Anti Ice T/O Config, Reduced or Normal Thrust Bleeds (On or Off) Emergency Actions Before & After V1 Eng.Out SID. Return or Divert to Altn. Proceedures After Take Off SID Routing Safety,Trans & 1st Cleared Altitude Communication Failure Use Of Radar

Before Takeoff

Any Change to Before Start Brief <u>Review Following:</u> F/D (MCP Setting) Initial Climb Altitude SID Check V1, VR, V2 LNAV or Heading

Descent/Approach

Destination and Alt. Weather ILS, VOR, ADF Setting <u>Review Following:</u> STAR Approach DA(H), MD(H),VDP, MAP Go Around Missed Approach Runway Condition & Lighting Taxi After Landing Communication & Lighting Diversion to Alternate Diversion to Alternate Destination & Alt. Holding Fuel Landing Configuration Use of Autobrake Taxi In Proceedures

www.737ng.co.uk Jan 2008

ian@737ng.co.uk